






FROM SOURCE TO SITE




Installation instructions


ORLTL-R-15W | ORLTL-R-35W

ADAPTOR INSTALLATION DIAGRAM




ADAPTOR DISASSEMBLY DIAGRAM






① Wire: 0.75mm², 18AWG

② Screw assembly to withstand Torque: Max.5kgf.cm



Normfair 3 phase track adaptor is universal compatible. It will work with the following brand track:
STAFF, NORLUX, GLOBAL, NUCOAND NORDIC
ONE PARTADAPT IT ALL!



We recommend that this product is installed by a competent person in accordance with the latest edition of the IET Wiring Regulations BS 7671 "Requirements for Electrical Installations" and the Buildings Regulations, as may be applicable subject to the location and country of the job or installation.

For more information and installation guide lines please refer to "Guide on Lighting Risks and Regulations" which can be downloaded from the website:

https://www.orient.com/content/files/orlight/resources/Guide_on_Lighting_Risks_and_Regulations_2020.pdf

NOTE – Light fittings in general can become hot whilst in operation. It is advisable that they do not come into contact with any flammable materials such as fabrics, furniture, soft furnishings or touched during/after operation.

* Please note, all information contained within this instruction manual is provided in good faith. We will not be held responsible for any losses incurred as a result of any inaccuracies contained within this document.